

# Caliber<sup>®</sup> TraxMat

## Installation Instructions for Part No. 13210 & 13211

### HARDWARE INLCUDED:

Qty	Description
1	TraxMat
2	8 Pack of Stainless Steel Screws (72" TraxMat Comes with 3 Packs of 8)

### TOOLS REQUIERED:

Power Screwdriver  
#2 Phillips Drill Bit

**NOTE:** Screws supplied are for mounting TraxMat to wood trailer decks. If mounting to other surfaces, pilot holes may have to be drilled.

**STEP 1:** Position TraxMat on trailer deck where protection and traction is desired.

**STEP 2:** At one end of the TraxMat place a screw in each corner  $\frac{3}{4}$ " in from each edge. Install with power screwdriver just until TraxMat begins to compress slightly, it is not necessary to over compress TraxMat.

**HELPFUL HINT:** Ideal installation conditions would be 70° F and sunny. With these conditions you will only need to slightly pull on the TraxMat to stretch it while installing the remaining screws. If this is not done the TraxMat will bunch up and become wavy looking when the temperature is above 70° F and sunny. If TraxMat is installed below 70° F it will just bunch up more when it becomes hot outside.

**STEP 3:** At the other end, pull the TraxMat tight and place screws in both corners  $\frac{3}{4}$ " in from each edge. Now all four corners of the TraxMat should be screwed down.

**STEP 4:** Space the remaining screws along the two long sides evenly.

Caliber<sup>®</sup>