



Setup instructions for Indoor CarCapsule

1. Remove your Indoor CarCapsule from its shipping box and unfold it. Spread it out equally on all sides and fold the “top cover” portion back toward air intake of the CarCapsule. **(fig.1)**
2. Lining up the intake hole; place the fan panel onto the Velcro pad. **(fig.2)**
3. Feed the fan power connector through the access port at the bottom-front of the base-mat, and plug in the 12V connector. **(fig.3)**
4. Center your vehicle to the base-mat and drive onto it. **(fig.4)**
5. Unfold the top cover of the CarCapsule over your vehicle while trying to avoid pulling it across the cars finish. **(fig.5)**
6. Mate the base-mat to the top cover by zipping its perimeter. One zipper on each side. **(fig.6)**
7. Power up the fan and watch it fill your CarCapsule. **(fig.7)**
8. Once fully inflated install the filter by pushing the brim of the filter into the flap provided on the outside of the air intake. **(fig.8)**

