



Setup Instructions for Outdoor CarCapsule

1. Remove your Outdoor CarCapsule from its shipping box and unfold it. Then spread it out equally on all sides and fold the top cover portion back, toward the air intake port of the CarCapsule. Center your car/bike/vehicle to the base-mat on a solid, debris-free surface and drive onto it. **(fig.1)**
2. Feed the fan 12V power connector through the access port under the intake hood. (Some models may include ONE or TWO fans and filters). **(fig.2)**
3. Lining up the intake holes; place the fan panel onto the Velcro pad on the inside of the top cover. **(fig.3)**
4. Install the plastic support, and filters inside the intake hood, pressing firmly on the Velcro pad. (Some models may include ONE or TWO fans and filters). **(fig.4)**
5. Unfold the top cover of the CarCapsule over your vehicle while trying to avoid pulling it across the cars finish. **(fig.5)**
6. Mate the base-mat to the top cover by zipping its perimeter. (One zipper on each side). **(fig.6)**
7. Power up the fan and watch it fill your CarCapsule. **(fig.7,8)**

