



Magna-Pure In-Line Filter: Installation Instructions

WARNING: Prior to installing the Magna-Pure in-line filter, the steering system MUST be properly flushed to remove old/contaminated power steering fluid.

1. Cut the power steering return hose from the steering gear to the power steering pump.
2. Slide a hose clamp over each end of the hose, install filter and position hose clamps.

NOTE: The FLOW arrow must point toward the power steering pump.

3. Fill power steering reservoir to proper level with manufacturer recommended fluid type.
4. Start the engine and begin bleeding the system of air by cycling the steering wheel from lock to lock. Repeat as needed.
5. Top-off the power steering reservoir, if needed.
6. If assist is smooth, bleeding is complete. If assist is erratic, more bleeding is required.
7. Fill out the enclosed Power Steering Service Interval sticker (recommended service interval is 30,000 miles) and affix in the engine compartment.

