

CARGO APRON

HOW TO USE

INSTALLATION INSTRUCTIONS

STEP 1

Unfold the CARGO APRON with the closed box end against the back of the rear seats, and the flap hanging out the rear of the vehicle (see figure 1).



Figure 1

STEP 2

Place the cord that is at the box end over the right and left headrests (see figure 2).



Figure 2

STEP 3

Unfold one side of the CARGO APRON, and suspend the side panel cord to the side window glass with the two suction cups. Space the suction cups, from side to side, and up and down according to the shape of the window. If the window has defrost element lines, the suction cups need to be placed between the lines. Repeat on the opposite side of the vehicle (see figure 3).



Figure 3

STEP 4

Pull the flap toward you to cover the bumper. Use the sliding cord locks on each side, and at the head rest to take up any slack in the suspension cords (see figure 4).



Figure 4

REMOVAL INSTRUCTIONS

STEP 1

Remove the cord from the headrests.



Figure 5

STEP 2

Fold the rear flap into the cargo area (see figure 5).



Figure 6

STEP 3

Remove the suction cups from the windows by lifting the small edge tabs. Place the suction cups and cord in the middle and fold the panels (see figure 6).



Figure 7

STEP 4

Fold in thirds (see figure 7 and 8).



Figure 8

STORAGE

Roll the CARGO APRON up from the rear of the vehicle and secure with the cord loop and sliding lock (see figure 9).



Figure 9