



**4077**  
**1957 CHEVY PASSENGER CAR**

NOTE: Stock turn signals and light bar are removed. Aftermarket turn signals must be used for this grille.

1. Remove bumper, light bar and stock grille.
2. Remove center vertical support.
3. Center vertical support bar has a section which sticks out forward that the light bar is attached to. This section must be cut off of support. For saw line, cut where the front nose is cut off making front all the same line. Replace support.
4. Now you're ready to install Billet grille, by inserting top first. Top tabs should mount in factory mounting holes. Install bolts in top tabs and leave loose. Now mark the location of bottom tabs onto splash apron. It may be necessary to put bumper back on car to get proper spacing for bottom tabs. This is recommended for the best fitment.
5. Remove bumper and [billet grille](#). Drill 1/4" hole at the marked location of bottom tabs.
6. Install grille and bumper. Aftermarket turn signal lights will need to be relocated behind grille.