

# #4112 1962-64 Chevy Nova Installation Instructions



- Step 1 Remove the 2 bolts from top of hood latch support. Figure No. 1
- Step 2 Remove the top & bottom bolts from side supports of factory stock grille. Figure No. 2
- Step 3 Remove the blinker lens cover from each side.
- Step 4 Remove the bolt that secures the bottom of the hood latch in place. Figure No. 3
- Step 5 At this point the entire factory stock grille should be able to be removed from the car.
- Step 6 Remove all rivets that hold the hood latch support to the factory stock grille.
- Step 7 Grind two rivets holding the side supports onto the factory stock grille, then cut as shown in figure No. 4 & No. 5.
- Step 8 Reinstall side supports at original mounting position. See figure No. 6 for reinstalled side brackets.
- Step 9 Cut hood latch support as shown in figure No. 7. Figure No. 8 shows final results.
- Step 10 Attach screw clips at each side bracket support and top latch support. Use #8 x 5/8" screws to attach [billet grille](#) in place. See figure No. 3 for screw clip attachment.

