



Installing Jon Boat Front Support Bunk

P/N 27850

1. Attach one short bunk bracket to each support bracket with 1" carriage head bolts. Place washers and nuts underneath.
2. Attach bunk support brackets to trailer tongue with 3" or 4" hex head bolts (as fits your trailer) and 3/8"-16 nuts.
3. Center the carpeted bunk board in the bunk brackets and secure with #14 x 3/4" Phillips head screws on each side.
4. Adjust to desired height.



TOOLS REQUIRED:

- 1 -- Phillips screwdriver
- 2 -- 9/16" Wrenches

PARTS INCLUDED:

1	2 Ft. Carpeted bunk	P/N 27831
2	Bunk support brackets, galv	P/N 7851G
2	Short bunk brackets	P/N 28104Z
2	3/8"-16 x 1" Carriage head bolts	P/N 11046
4	3/8"-16 nuts	P/N 10810
4	#14 x 3/4" Phillips tapping screws	P/N 11006
2	3/8" USS Flat washers	P/N 10960
2	3/8"-16 x 3" Hex bolts (for 2" tongue)	P/N 11035
2	3/8"-16 x 4" Hex bolts (for 3" tongue)	P/N 11037

