Installation Instructions

T-Connector





Chevrolet Equinox

GMC Terrain









5. Reposition the access panels, trays and truck floor panels and reattach the threshold.

WARNING

All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed. For initial test, reset vehicle electrical system by temporarily removing the key from the ignition.

144

WARNING

Overloading circuit can cause fires. DO NOT exceed lower of towing manufacturer rating or:

- Max. stop/turn light: 1 per side (7.5 amps)
- Max. tail lights: (7.5 amps)

Read vehicle's owners manual & instruction sheet for additional information

TOOLS NEEDED:

Trim Panel Remover, Test-probe

NOTE

Some vehicles may require your local GM dealer to activate the towplug option. Test the tow plug for power before installation.

- Open the vehicle's rear tailgate. On the driver's side, remove access panels, threshold, trunk floor panels and trays . Set aside all items removed being careful not to damage parts. Several trim panel fasteners will need to be removed to remove the panels.
- On the driver's side, Being careful not to damage clips, partially remove the lower interior trim panels on driver's side of the vehicle only Set aside all items removed being careful not to damage parts.
- Locate the grey 4-pin housing taped to the taillight harness on the Driver side . All connector surfaces should be clean and free of dirt.
- 4. Insert the T-Connector harness into the vehicle's Tow-Plug harness and lock into place. Be careful not to damage the locking tabs and be sure that connectors are fully inserted with locking tabs in place.

Secure the remainder of the T-Connector harness with the cable ties provided, to prevent damage or rattling and being careful to avoid any areas that would pinch, cut or melt the wire.

NOTE

Route the 4-Flat through the driver's side trim panel into side storage compartment and store there when not in use.