


Installation Instructions

T-Connector



Toyota Sienna



TOOLS REQUIRED:

10mm Socket & Ratchet or 10mm Wrench, Drill (3/32" Drill Bit), Test-probe

1. Carefully remove both of the vehicle's rear taillight housings by removing the two bolts that hold each taillight in place **A B**.
2. Remove vehicle rear threshold by unscrewing the three cargo bolts and carefully prying the threshold away from the vehicle **D E**.
3. Carefully pull back driver's side trim panel, being careful not to break any clips or tabs.
NOTE
Vehicle options vary, carefully pull back panel if equipped with rear speaker cover. Screws or clips holding cover may come off during panel removal **F**.
4. On Passenger's side, open the vehicle's jack storage compartment to expose the opening to the taillight assemblies **G**.
5. From the Passenger side, route the T-Connector's harness ends containing the **green** wire out from inside the vehicle through the taillight opening **C**.

6. Disconnect the vehicle's wiring harness connector from the taillight assembly, being careful not to damage the locking tabs. Plug the T-Connector's harness between these separated halves.
7. Route the harness containing the **yellow** wire across the vehicle under the threshold cover removed in step 2. Route the T-Connector harness containing the **yellow** wire out from inside the vehicle through the taillight opening. Repeat step 6 using harness containing the **yellow** wire.
8. Locate a suitable grounding point near the connector such as the vehicle's frame or cross member. (Do not drill into vehicle floor or bed. Do not drill into any exposed surfaces.) Clean dirt and rustproofing from area. Drill a 3/32" hole and secure white wire using eyelet and screw provided.

⚠ CAUTION

Verify what is behind any surface prior to drilling to avoid damage to the vehicle and/or personal injury. Do not drill into any exposed surfaces.

⚠ WARNING

All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed.

9. On the Passenger side, mount the T-Connector black converter box in a out of the way place with the screw or cable tie provided and secure all loose wires with cable ties.

10. Tuck the **yellow** wire under the threshold panel and secure. Re-install plastic trim panels, jack storage panel and taillights.

NOTE

Store 4-Flat in rear cargo area when not in use.

⚠ WARNING

Overloading circuit can cause fires. DO NOT exceed lower of towing manufacturer rating or:

- Max. stop/turn light: 1 per side (2.1 amps)
- Max. tail lights: (4.2 amps)

Read vehicle's owners manual and instruction sheet for additional information.