



Installation instructions



REMOVE CARGO NET LATCH FOR REMOVAL OF TRIM PANELS.



A - LEFT TRIM PANEL
B - RIGHT TRIM PANEL
C - REAR THRESHOLD



WHITE TOW PLUG

1. Locate the vehicle wiring inside the vehicle's trunk by removing each of the plastic trim panels. There will be connection points matching the ends of the T-connector adapter.
2. Beginning with the driver's side, separate the vehicle's wiring connectors, being careful not to break the locking tabs. Attach each end to the T-connector containing the yellow wire. Ensure that the connectors are fully inserted with locking tabs in place.
3. Remove rear threshold inside the trunk and route the wire to the passenger side of the vehicle. Repeat step 2 using the T-connector containing the Green wire.
4. Locate a suitable grounding point near the adapter. (Do not drill into vehicle floor or bed). Clean dirt and rustproofing from the area. Drill a 3/32" hole and secure the White wire using the eyelet and screw provided.
5. Test the installation with a test light or trailer. All connections must be complete for the T-connector adapter to function properly. Secure the black box to the vehicle using the screw or cable tie provided. Reattach all trim panels.

This unit is rated for **4** amps per circuit.

