

Installation instructions



1. Locate the vehicle's tail light wiring harness underneath the truck bed near the passenger side frame rail. This harness will have a connection point with connectors matching the ends of the T-connector harness.
2. Separate the vehicle's connectors, being careful not to break the locking tabs. Check to see that the mating surfaces of the connectors are free of dirt and clean. If necessary.
3. Insert the T-connector harness between the vehicle's connectors.
4. Locate a suitable grounding point near the connectors such as the vehicle's frame or crossmember (Do not drill into vehicle floor or bed). Clean dirt and rustproofing from area. Drill a 3/32" hole and secure white wire with eyelet using screw provided.
5. Route the T-connector harness to the center of the vehicle and secure wire to vehicle crossmember or other mounting point using electrical tape or tie straps (not provided).
6. Test the installation with a test light or trailer.

This unit is rated for 4 amps per circuit.

