

Installation Instructions

T-Connector



Ford Explorer



DRAW-TITE®

TOOLS NEEDED:

Wire Cutters, Test-probe

1. Locate the vehicle's Tow-Plug harness underneath the vehicle, on the passenger's side. The connection point will be behind the rear tire and have connectors matching the T-Connector harness **A**.

Separate this connector, being careful not to break the locking tabs. All connector surfaces should be clean and free of dirt.

2. Insert the T-Connector harness into the vehicle's Tow-Plug harness and lock into place.
3. Route the T-Connector harness along the inside of bumper toward the center of vehicle.

⚠ WARNING

Route the wire being careful to avoid any hot pipes, heat shields, the fuel tank or any other points that may pinch or break the wire.

4. **⚠ WARNING**

All connections must be complete for the T-Connector to function properly. Test and verify installation with a test light or trailer once installed.

5. Secure all loose wires and mount the Trailer Tow Harness in an accessible location with a bracket or electrical box (not included).

⚠ WARNING

Overloading circuit can cause fires. DO NOT exceed lower of towing manufacturer rating or:

- Max. stop/turn light: (7.5 amps)
- Max. tail lights: (7.5 amps)

Read vehicle's owners manual & instruction sheet for additional information.

Check out the collection of trailer hitches and towing we offer.