

## Installation Instruction LED Taillights

## 2003 - 2006 Chevrolet Silverado 1500/2500/3500



Tools needed phillips head screwdriver.



Open tailgate and remove the phillips head screws located inside the tail gate area.



Once the screws are removed, you will be able to pull tail lens straight out.



Remove the 4 bulbs socket from the stock lens. Remove the three bulbs leaving the side marker light installed.



Install the resistor boxes in a location out of the way of the taillight housing.



Plug the taillight sockets into the stock wire harness. Make sure the green wire match the green and black to black.



Reinstall the side marker light into the new housing. Connect the resistor box to the wire harness.

2003 - 2006 Chevrolet Silverado 1500/2500/3500

Reinstall the taillight back on to the vehicle. Make sure all functions are working properly before driving.

CG LIGHTS LED TAILLIGHTS