





Remove the two torque screws that hold the taillights assembly to the truck.

Pull the taillights assembly straight out to remove.



Pull the red clip down to remove the plug from stock taillights assembly.

Plug in the new L.E.D taillights assembly to the stock wire harness.

Install the taillight using the two torque screws.



Make sure taillights is working properly before driving.