



Part # 20161
2011-UP Ford Explorer
3.5L V-6 2/AWD

CGS Installation Instructions

Thank you for choosing a CGS Air Intake System™ to power your vehicle. These instructions will take you through the installation of your new Air Intake System.

Kit includes:

Qty.	Description
1	Silver Powder Coated Tube
2	Band Clamps
1	aluminum Bung
1	Black rubber insert
2	Allen screws
1	3" Red Silicon Boot
1	3.5" CGS High Flow Filter

1) Remove stock Air Intake

First start by removing the stock Intake system. You will need to unscrew the sensor from the intake and remove it so that you can reinstall it later. Unplug the rubber breather hose on the back right side on the stock intake. Also unplug the breather hose on the left side by pushing down the little gray clip.

2) Installing your CGS Air Intake System

Now that the stock system is removed you can proceed to install your new CGS system. As shown in the 1st illustration install the Red Silicon Boot to the throttle body and secure with band clamp. Next insert the powder coated tube into the red silicon boot as shown in the photos. Proceed to install the two breather hoses onto the intake system. Now install the CGS Filter on the other end of the intake tube. Now you will bolt the brack to the core support. Last you will install the sensor in to the new CGS Intake tube. Once the Intake system is positioned and lined up correctly, install clamps at all connections and tighten.

3) Final checklist

Once completed, check to make sure all the clamps and bolts have been securely fastened. That's it, a simple install with a lot of results. **Congratulations!** You just installed more horsepower to your SUV by allowing it to breathe easier with a CGS Air Intake System™.

Thank you again and enjoy your new CGS Air Intake System™.

Don't forget to ask your local CGS Dealer about a CGS Cat-Back Exhaust System for your Ford Explorer

