

## CGS Installation Instructions

Thank you for choosing a CGS Air Intake System™ to power your vehicle. These instructions will take you through the installation of your new Air Intake System.

### Kit includes:

Qty:	Description
1	Plastic Air Tube
1	Black Boot w/clamp
2	Large Band Clamps
1	3/4" Red Silicon Boot
1	3/4" CGS High Flow Filter
1	Red Silicon beather hose
1	Black powder coated bracket
1	Rubber grommet
1	Billet Aluminum fitting



### 1) Remove stock Air Intake

First start by removing the Intake pipe by unbolting the clamp at the throttle body. Then slide the breather hose that is in front of the oil filler cap off. Next you will remove the clamp at the air filter box and remove the filter box with the rest of the system but be sure and not remove the Mass Air Flow Meter.

### 2) Installing your CGS Air Intake System

First start by taking the Plastic Air Tube and installing the Black boot on the large end of the tube. Now you will slide that end onto the Throttle Body and snug it up but do not tighten it. Install the Red Silicon Boot and Mass Air Flow Meter to the other end. Before the filter is installed, the bolt below the filter will need to be removed and reinstalled with the bracket included in the kit. Proceed to install the Filter on the other end of the Mass Air Flow and the filter clamp will go around the bracket also. Last the red beather hose is connected to the intake, and to the engine, where the factory one was removed. Once the Intake system is positioned and lined up correctly, install clamps at all connections and tighten.

### 3) Final checklist

Once completed, check to make sure all the clamps and bolts have been securely fastened. That's it, a simple install with a lot of results. **Congratulations!** You just installed more horsepower to your truck or SUV by allowing it to breathe easier with a CGS Air Intake System™.

**Thank you again and enjoy your new CGS Air Intake System™.**

