

## CGS Installation Instructions

Thank you for choosing a CGS Catback Exhaust System™ to power your vehicle. These instructions will take you through the installation of your new catback exhaust system.

**Kit includes:**

Qty.	Description	Part#
1	Headpipe	300-1038
1	CGS Muffler	83001
3	3" Clamps	
1	tail pipe	300-1039
1	3 Stainless Steel Tip	93530

### 1) Remove stock exhaust system

First start by removing the stock Exhaust system by unbolting the clamp at the front of the muffler as shown in the first picture. Then slide the complete system carefully towards the rear off of the rubber hangers. Remove the system from under the truck. Cutting may be required for removal on certain models.

### 2) Installing your catback exhaust system

Make sure that all existing rubber Hangers are still in place. Install the headpipe by sliding it over the stock pipe. Proceed to install muffler onto headpipe with the center in the inlet and offset at the outlet and closest to the Frame of the truck outlet. Install the overaxle pipe onto the muffler and insert the bracket into the rubber hanger. Next the exit pipe will install and insert the bracket into the rubber hanger. Once the exhaust system is positioned and lined up correctly, install clamps at all connections. Install the stainless steel tip and tighten bolts.

### 3) Final checklist

Once completed, check to make sure all the clamps and bolts have been securely fastened. That's it, a simple install with a lot of results. **Congratulations!** You just installed more horsepower to your truck by allowing it to breathe easier with a CGS Catback Exhaust System™.

**Thank you again and enjoy your new CGS Catback Exhaust System™.**

