


CGS Installation Instructions

Thank you for choosing a CGS Catback Exhaust System™ to power your vehicle. These instructions will take you through the installation of your new catback exhaust system.

Kit includes:

Qty.	Description	Part#
1	Headpipe	300-1066
1	CGS Muffler	82501
3	2 1/2" Clamps	
1	tailpipe	300-1067
1	3 Stainless Steel Tip	93525



Picture displayed for reference and may vary from actual product

1) Remove stock exhaust system

Start by removing the stock Exhaust System. First you will need to measure back 4" from the stock flange that holds the head pipe on and mark and then cut it. Then slide the complete system carefully towards the rear off of the rubber hangers. Remove the system from under the truck.



2) Installing your catback exhaust system

Make sure that all existing rubber Hangers are still in place. Install the headpipe over the stock pipe and secure with a clamp but do not tighten. Proceed to install muffler onto headpipe. Next the tailpipe will install and insert the brackets into the rubber hangers. Once the exhaust system is positioned and lined up correctly, install clamps at all connections. Install the stainless steel tip and tighten bolts.



3) Final checklist

Once completed, check to make sure all the clamps and bolts have been securely fastened. That's it, a simple install with a lot of results. **Congratulations!** You just installed more horsepower to your truck by allowing it to breathe easier with a CGS Catback Exhaust System™.

Thank you again and enjoy your new CGS Catback Exhaust System™.

