



Manufacturers and distributors
of quality chassis, suspension, driveline
and components

Radiator Mount Kit

Part # 4111

Parts List:

- 2...Radiator Mounts
- 2...1/4" X 1-1/4" Detent Pins
- 2...Mounting Sleeves

- 1...Bolt the radiator mounts to the radiator. (Customer must supply the mounting bolts.)
- 2...Position the radiator in the car to the correct height. Cut the radiator mounts off to lower the radiator if needed.
- 3...Slide the mounting sleeves onto the radiator mounts half way. Hold the radiator in place and tack weld the mounting sleeves to the frame. Remove the radiator and weld the sleeves completely.
- 4...Install the radiator with the mounts. Drill a 1/4" hole through the bottom of both mounting sleeves and install the 1/4" detent pins.