



TAILLIGHT BEZEL INSTALLATION

Instructions explaining how to install chrome taillight bezels, and chrome accessories in general.

YOU'LL NEED

- Clean work area, free of airborne dust
- Vehicle and bezel temperature above 65°F (use hair-dryer to warm up the surface if the temperature is below 65°F)
- 3M Adhesive Cleaner (PN 08984) or equivalent (optional)
- Soft clean cloth.

NOTE: Handle with care!
Protect your taillight bezel from impact and excessive bending which will damage its appearance.

PRE-INSTALLATION

- **DO NOT REMOVE RED TAPE LINER**
until instructed to do so.
- **LAY OUT AND TEST FIT OF THE BEZELS BEFORE STARTING.**
Check that the shape and cutouts on each piece properly conform to the surface area on both passenger and drivers side of the car. Note the proper placement and alignment.
- **CLEAN RECEIVE SURFACE JUST PRIOR TO INSTALLATION.**
Use 3M Adhesive Cleaner (or equivalent) to clean the area thoroughly. Receiving surface must be dry and clean of dirt and grime.

INSTALLATION

- **REMOVE THE ENTIRE RED LINER**
Protect exposed tape from contaminants.
- **HOLD THE PIECE AT A 90° ANGLE TO THE SURFACE,**
and touch the very top edge to the surface, observing your placement and alignment guides. If you need to adjust placement, simply raise the piece past 90° and lift off.
- **ONCE YOU GET THE PLACEMENT RIGHT**
press down across the top of the piece to tack it in place. Complete installation by pressing down across the piece with a soft clean cloth, moving top to bottom.
- **LASTLY APPLY PRESSURE OVER ENTIRE SURFACE INCLUDING EDGES**
to ensure that the tape completely adheres to the surface. Check your edges and re-apply pressure where necessary. You may use any non-abrasive stainless steel cleaner to keep your taillight bezels shining bright!

IMPORTANT!

Once the tape adheres to the vehicle, the bezel cannot be taken off without being damaged. The surface of the vehicle, however will not sustain any damage if the bezel is removed in the future.