

INSTALLATION INSTRUCTIONS For Part #'s:

10900

NOTE:

US BEFORE ATTACHING MIRROR, WE RECOMMEND THAT YOU CLEAN VEHICLE MIRROR. YOU MAY ALSO WISH TO APPLY A THIN COAT OF WAX.
REMOVE CUSTOM TOWING MIRROR BEFORE ENTERING AUTOMATIC CARWASHES. USE EXTRA CAUTION WHEN APPROACHING TIGHT SPACES, SUCH AS ATM TERMINALS, AND OTHER DRIVE-THROUGH SERVICES.

