



**'99-'04 Mustang
Honeycomb Trim Panel**
**CDC #'s: 105050 - GT
 105051 – Mach 1**

Note: Read installation instructions before starting.



Kit Components:

- Center Panel
- Driver Side Panel
- Passenger Side Panel

Tools Required:

- Soft Clean Cloth
- Rubbing Alcohol
- Heat Gun or Hairdryer

Attention:

Failure to follow instructions may result in loss of this product. Classic Design Concepts is not responsible for improperly installed Honeycomb Trim Panel.

Trim Panels must be installed at a temperature of 70° F or above. If necessary, warm the vehicle and Trim Panels with a heat gun or hair dryer.



1. Remove the license plate from the vehicle.
2. Heat the factory *GT* and *Ford* emblems and surrounding areas with a Heat Gun or Hairdryer to soften the adhesive tape securing them to the trunk lid. Carefully remove them from the trunk lid.

Note:

Use caution when using a Heat Gun, paint damage can occur!

3. Clean Trunk Lid where the Trim Panels will attach to the vehicle.
4. Attach the Factory Emblems to the Honeycomb Trim Panel(s) if applicable.
5. Wipe the Trunk Lid areas, where the Trim Panels will be mounted, with Rubbing Alcohol to remove any dirt, wax and glue residue.
6. Before peeling the backing from the bonding tape, test fit the Trim Panels to the vehicle.
7. Apply the Center Trim Panel first. Peel 3" to 4" of the red backing from the acrylic bonding tape and place the Panel onto the trunk lid. When the Panel is properly positioned, finish peeling the red backing from the bonding tape and firmly press over the tape areas to seat tape to the trunk lid.
8. Apply either side Panel next. Peel 3" to 4" of the red backing from the acrylic bonding tape and place the Panel onto the trunk lid, aligning the outer edge of the Trim Panel with the edge of the trunk lid. When the Panel is properly positioned, finish peeling the red backing from the bonding tape and firmly press over the tape areas to seat tape to the trunk lid.
9. Repeat on the other side.