



Hood Pin Appearance Kit Instructions CDC# 105109 All Models

Note: Read installation instructions before starting.



Component List:

- 2-Hood Pin and Plate assembly
- 2-Retainer Pin and cable assembly

Tools Required:

- Isopropyl Alcohol
- Soft, clean rag
- Drill Motor and Bit
- Screw Driver
- Small Screws

I. Preparing the hood for application:

1. Thoroughly clean the hood in the areas where the Hood Pins will be attached.
2. Locate a suitable mounting location for the eyelet end of the Retainer Pin/Cable assembly on the bottom side of the hood.
3. Place the Hood Pin and Plate assembly on hood to determine the best installation location, keeping in mind the cable attachment on the bottom side of hood.

Note: Hood Pin/Plate assembly must be adhered to a flat surface to ensure proper contact of mounting tape.

II. Hood Pin and Plate assembly install

When desired attachment location has been determined:

1. Rub installation area with soft, clean rag dampened with Isopropyl Alcohol to remove all wax.
2. Peel the red backing from the adhesive tape on the bottom of Pin/Plate assembly.
3. Lightly set Pin/Plate assembly on hood in desired location. Verify location and reposition if necessary.
4. When ready, apply pressure to the Pin/Plate assembly to seat the adhesive tape to the hood.

III. Retainer Pin and Cable install

When Pin/Plate assembly attachment is finished:

1. Place Retainer Pin through hole in Hood Pin.
2. Pull vehicle hood release.
3. Lift hood of vehicle to a slightly open position.
4. Determine the best location for cable attachment to the bottom side of the vehicles hood.
5. Secure the eyelet end of the cable to the bottom side of hood, or other suitable location. Screw not included in kit.

CAUTION! DO NOT DRILL THROUGH THE OUTER SURFACE OF THE HOOD!