



Cognito Motorsports, Inc. Lower Shock Mount Bracket Kit for '01-'09 GM 8-Lug

Introduction

- Installation requires a qualified mechanic.
- Read instructions carefully and study the pictures (if included) before attempting installation.
- Check the parts and hardware packages against the parts list to assure that your kit is complete.
- Always wear safety glasses when using power tools.

Parts List

- (2) Lower shock mount bracket
- Instruction sheet

Installation Instructions

1. Remove the lower shock bolts from the factory lower shock mount bracket.
2. Then remove the 2 bolts holding each factory lower shock mount bracket to the lower control arm.
3. Discard the factory mount and replace with the extended Cognito shock mounts as shown in Figure 1, torque bolts to 50 ft-lbs.. Replace the shock to its new mount with the factory hardware previously removed, and torque to 65 ft-lbs. If you are using an aftermarket shock, you may not need to use the Cognito extended shock mounts depending on the length of the shock. Consult with Cognito Motorsports if needed.



Figure 1: Cognito lower shock bracket installed.