



**Cognito Motorsports, Inc.**

## **Cognito Motorsports shocks by FOX Install Instructions**

Application: Front shocks for 2001-2010 GM 1500HD, 2500, 2500HD, 3500HD

See figures 1 and 2 below, If using the stock upper control arm on your vehicle, the spacer must be in position directly under the lock nut as shown in Figure 1. If using a Cognito Motorsports Upper Control Arm Kit, place the spacer against the shock body as shown in Figure 2. The torque spec for the M12x1.25 upper stud nylon lock nut is 77 ft-lbs.



**Figure 1: for use with stock upper arm**



**Figure 2: For use with Cognito upper arm**