



## Colgan [Mirror Bra](#) Installation Instructions

Before beginning installation, let mirror cover warm up in the sun for 15 minutes for maximum elasticity. If this is not possible, a space heater can be used, but only under constant supervision!

1. Stretch elastic ring and slide mirror cover over mirror. (Hook and loop fastener should be on top, Hook and loop fastener should be on bottom)



2. Stand facing the painted side of the mirror
3. With both hands, start at the outside edge of the mirror and work excess vinyl material that is bunched up in the elastic ring towards the neck of the mirror (right hand working vinyl over at the top and left hand working vinyl over at the bottom)



4. Pinch the neck of the mirror with left hand and pull Velcro loop down with right hand towards Velcro hook at the bottom of the mirror cover and attach Velcro to hold it in place



5. Repeat steps 2 and 3 until proper fit.

6. The edge of the Velcro loop should more or less fit the far edge of the Velcro hook

7. Do the same for passenger side.

