

Please take time to read and understand these installation instructions.

WARNING: dB Mufflers are **NOT** universal mufflers. dB Mufflers are designed and acoustically approved for specific vehicle and engine configurations. Use of dB Mufflers for applications other than CORSA's specific recommendation may result in an unsatisfactory sound. dB Mufflers are designed with specific inlet and outlet configurations. Installing the outlet side of the muffler to the inlet pipe may result in an unsatisfactory sound.

Bill of Materials: (1) Muffler Assembly

Inlet of muffler is expanded to slide over a 4" diameter pipe. Outlet of muffler is 4" diameter.

NOTE: Muffler drain hole should be positioned at bottom rear of muffler once mounted to evacuate condensation.

CORSA recommends that installation of this system be performed by a qualified service center or professional muffler installer who has the necessary equipment, tools and experienced personnel. However, if you decide to perform this install, the use of a hoist and an additional person will be required.

CAUTION: Never work on a hot exhaust system. Allow time for the vehicle to cool. Always wear eye protection when working under a vehicle.



INLET SIDE OF
MUFFLER IS EXPANDED
AND NOTCHED.



DRAIN HOLE SHOULD BE
POSITIONED AT BOTTOM
REAR OF MUFFLER
ONCE MOUNTED.