

# Fitting instructions

**CORTECO**

**80001210**  
**80001211**



The Perfect Change.

BMW 5-er (F07) GT  
BMW 5-er (F10)  
BMW 5-er (F11) Touring  
BMW 7-er (F01-F02)

10.09 →  
03.10 →  
09.10 →  
10.08 →

