

Fitting instructions

CORTECO

80001210
80001211



The Perfect Change.

BMW 5-er (F07) GT
BMW 5-er (F10)
BMW 5-er (F11) Touring
BMW 7-er (F01-F02)

10.09 →
03.10 →
09.10 →
10.08 →

