

Fitting instructions

CORTECO

8000063
8000064



The Perfect Change.

BMW 1er/1 series (E81-E87)
BMW 1er/1 series (E82) Coupe
BMW 1er/1 series (E88)
BMW 3er/3 series (E90;E91)
BMW X1 (E84)

09.04 →
10.07 →
03.08 →
01.05 →
10.09 →

< 10 min

