



27-35

DOOR PANEL INSTALLATION INSTRUCTIONS

IMPORTANT

- READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL PANELS.
- MAKE SURE YOU HAVE THE CORRECT PANELS FOR YOUR AUTOMOBILE.
- COVERLAY® DOOR PANELS ARE NOT EXACT DUPLICATES OF FACTORY ORIGINALS.
- IF YOU PLAN ON COLORING YOUR COVERLAY DOOR PANELS, DO IT PRIOR TO INSTALL.

1. Remove old door panels:
 - a. Pop out the two window grommets on top of the door panel
 - b. Remove pull strap
 - c. Remove old door panel using a putty knife to lift along the edges
2. Position your Coverlay® door panel on your truck door. Make sure the new panel lines up with the original holes in the door's sheet metal and press into place.
3. Re-install pull strap and window holders.