



**RT Off-Road
LED Headlight Set
P/N: RT28104
Installation Instructions**



Kit Contents

Qty. 2 – LED Headlights

Qty. 2 – LED CANBUS Modules

Qty. 2 – H4 to H13 Adapter Harnesses

1. Install the included LED CANBUS Modules in line with the headlight wiring if required.

Note: Required for 07/18 JK Wrangler

2. Install the included H4 to H13 Adapter Harnesses in line with the headlight wiring if required.

Note: Required for 07/18 JK Wrangler

3. Install the headlights into the buckets with the 3 tabs on the headlights engaged into the bucket.

4. After installing both headlights check the aiming of the new beam pattern and make any corrections needed. The beam pattern is different when compared to an OE headlight assembly.

While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.

[View other custom and factory headlights made by Crown on our website.](#)