

# INSTALLATION INSTRUCTIONS

## 51451 & 51452 APPLICATIONS

Make	Model
Cadillac	Escalade
Chevrolet	Silverado
Chevrolet	Suburban
Chevrolet	Tahoe
GMC	Sierra
GMC	Yukon

### BRAKE CONTROL HARNESS



### NOTICE

All steps must be followed to ensure the CURT brake control harness will function properly. Once installed, test for proper function by following the brake control unit instruction manual.

### LOCATION GUIDE


#### Representative vehicle shown below

**BH1** - Under dash, left of steering column, near emergency brake pedal

**BH3** - Under dash, in junction box left of steering column



**BH3**   
E-brake

**BH1**   
Brake

  
Gas

# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Locate the black electrical junction box under the dash, to the left of the steering column. Remove the box cover and locate the empty vehicle connection point (A,B).

## Step 2

Insert the connector on the CURT brake control harness into the vehicle connection point. Make sure the connector is fully inserted with locking tabs in place (C).

## Step 3

Insert the brake control harness's black connector into the brake control's quick plug connector (D). Secure the brake control harness with the provided cable ties, avoiding any pinch points.

## Step 4

Complete the installation using the brake control instructions. Mount the unit as directed and perform test procedures as instructed in the brake control user manual.

