

# 55244

NISSAN XTERRA

## WIRING LOCATION GUIDE



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer



1. Locate the vehicles factory tow harness it will be located under the vehicle, behind the rear bumper on the passenger side location S7. **A**

2. Remove the protective cap and insert the 4-pin connector into the vehicles factory tow harness making sure the locking tab is in place.

3. Route the 4-Flat wire along the backside of the bumper to the center of the vehicle making sure to avoid areas that may pinch or cut the wire. Secure any loose [wire](#) with the cable ties provided.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.