

# INSTALLATION MANUAL

# 16090

## Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

## Weight Carrying Capacity

Gross trailer weight (GTW)	30,000 lbs.
Vertical load	7,500 lbs.

## Parts List

Item	Qty	Description
1	1	Spyder gooseneck
2	4	Rail pin
3	4	Rail clip

## Tools Required

None

## ⚠ WARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

## Product Photo



## NOTICE

Visit [www.curtmfg.com](http://www.curtmfg.com) for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

This product requires 5th wheel base rails to be installed.

Periodic inspection of your product should be performed to ensure all hardware and / or components remain secure.

# ASSEMBLY

## Parts List

Item	Qty	Description
1	1	Spyder gooseneck
2	4	Rail pin
3	4	Rail clip

## Step 1

Place the Spyder gooseneck hitch (#1) into the base rails. Insert the four provided rail pins (#2) through the rails and gooseneck and secure with the rail pin clips (#3).

