

# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Buick	LaCrosse

## WIRING LOCATION GUIDE

### PASSENGER CARS (P)

Representative vehicle shown below

P1 - Behind driver side taillight housing, outside of trunk

P2 - Behind passenger side taillight housing, outside of trunk

## CUSTOM WIRING HARNESS



## NOTICE

All steps must be followed to ensure the wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

- Panel trim removal tool
- Flat blade screwdriver
- Cutting tool

## ⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

# INSTALLATION / SAFETY INSTRUCTIONS

- Step 1**  
Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.
- Step 2**  
Remove the fasteners securing the rear scuff panel. Remove the scuff panel by pulling out on the bottom and then up. Take care not to damage the alignment tabs on the back.
- Step 3**  
Starting on the driver side, remove the push fastener, cargo fastener and Phillips screw from the felt liner.
- Step 4**  
Pull back on the felt liner to locate the vehicle taillight wiring harness connectors. The connectors will be similar to those on the custom wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs.
- Step 5**  
Insert the custom wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.
- Step 6**  
Route the custom wiring harness end with the green wire to the passenger side behind the removed scuff panels. Repeat step 4 on the passenger side using the harness end with the green wire.
- Step 7**  
When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.
- Step 8**  
Reinstall all items removed during install and reconnect negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

