11338 MAZDA 5

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

ITEM	LOTY	Parts		
ITEM 1	QTY 2	PART NUMBER CM-SP2	DESCRIPTION .250 x .88 x 2.25" SQUARE HOLE SPACER	
2	2	7/16 - 14 x 1 3/4	CARRIAGE BOLT	
3	2	3 8 - 16 x 4 1 2 CARRIAGE	CARRIAGE BOLT	
4	2	CM-SP18	.250 x 1.00 x 2.00" SQUARE HOLE SPACER	PASSENGER SIDE FRAME RAIL
5	1	CM-438-FW	7/16 " FISHWIRE TOOL	FRAME RAIL
6	2	HFN3816	HEX FLANGE NUT	
7	2	7/16-14	HEX FLANGE NUT	
HITCH MOD AND OUT T END OF FIS THREAD B TO KEEP S BOLT AS S FISHWIRE, BOLT THR AND OUT I USE FISHV	DILED END O UNTING HOLI THE ACCESS SHE ACCESS SHOWN PUL SPACER, AI OUGH FRAM MOUNTING H VIRE TO GUII	ND HOLE MOUNTING		BUMPER BEAM
NOTE	SOME VEHICLE	ES MAY FISHWIRE THROUGH END OF FRAME	DRIVER SIDE FRAME RAIL	MPER BEAM 7
	(3		ERCKYT AREAR
INSTA PRO NO	<u>LL TIME</u> DFESSION	: 24 LBS. NAL: 45 MINUTES D: 90 MINUTES S:		DESIGNED FOR USE WITH AALLMOUNT #55001 / 45501

INSTALLATION STEPS

- 1) Locate hitch between frame rails and raise hitch into position. Install 4 1/2" carriage bolts and square hole spacers as shown.
- 2) Enlarge existing holes in bumper beam where necessary and position hitch against bumper beam. Fishwire 7/16" bolts and square hole spacers into position as shown. Install hex flange nuts.
- 3) Torque all 3/8" fasteners to 45 lb-ft, and all 7/16" fasteners to 70 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

