11348 NISSAN VERSA (HATCH BACK AND SEDAN)

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT. ***DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.***

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS. ** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

Parts List FISHWIRE TECHNIQUE EISHWIRE TECHNIQUE INSERT COILED END OF FISHWIRE TOOL THROUGH HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL AND OUT THE ACCESS HOLE. PASS COILED END OF FISHWIRE THROUGH SPACER AND THREAD BOLT INTO COIL. KINK WIRE TO KEER SPACER, SPACER AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE HITCH DURING MOUNTING AND PREVENT LOSS OF BOLT / SPACER INSIDE FRAME RAIL. "NOTE: SOME VEHICLES MAY FISHWIRE THROUGH END OF FRAME" ITEM QTY PART NUMBER DESCRIPTION 2 1/2" WASHER 1 2 1/2-13 x 1 3/4 CARRIAGE BOLT 2 2 1/2" FISHWIRE TOOL 3 HFN 1213 HEX FLANGE NUT 4 3 7 3 CM-SP6 .250 x 1.00 x 3.00" SQUARE HOLE SPACER 5 .250 x 1.00 x 2.00" SQUARE HOLE SPACER 1 CM-SP12 6 CARRIAGE BOLT 1/2 - 13 x 2" 7 1 VEHICLE TOW LOOP 2 6 DRIVER SIDE 5 FRAME RAII 4 ENLARGE EXISTING HOLE FOR ACCESS TO ATTACHMENT HOLES Ø REMOVE UNDERBODY COATING (з` FROM JUST AROUND THE HOLE FOR WASHERS. DDDD 6) 2 6) DESIGNED FOR USE WITH BALL MOUNT # D-20 / 45520 3 HITCH WEIGHT: 29 LBS. FROM **INSTALL TIME** PROFESSIONAL: 30 MINUTES NOVICE (DIY): 60 MINUTES INSTALL NOTES: DRILLING ACCESS HOLE REQUIRED FISHWIRING REQUIRED

INSTALLATION STEPS

- 1) Remove undercoating from hitch mounting locations.
- 2) Enlarge existing hole under frame rail to 1" as shown above.

The FIRST Name in Towing Products™

- 3) Fishwire 1 3/4" carriage bolts with spacers through access hole and outmounting hole. Raise hitch into position, remove fishwires, install 1/2" washers, and secure hitch with flange nuts.
- 4) Place remaining carriage bolt and spacer onto tow loop and place small spacer on hitch. Raise passenger side and secure with flange nut.
- 5) Torque all 1/2" fasteners to 110 lb-ft. **PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.**

Trailer Hitches