

57000

NISSAN TITAN

NISSAN ARMADA

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Locate the vehicle's relay panel on the passenger side under the hood near the battery (A).
2. Remove the relay panel's cover, taking care not to damage the locking tabs.
3. Insert the blue relays into the positions labeled "TRAILER TURN RH" and "TRAILER TURN LH".
4. Insert the brown relay into the position labeled "TRAILER TOW NO. 2".

Note:
For vehicles not equipped with the factory OEM 7-Way, use CURT 55774 or similar.



