

YEARS: 2012-PRESENT

MAKE: AUDI

MODEL: A6

STYLE: SEDAN

**WARNING: NEVER EXCEED YOUR VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY**

**WEIGHT CARRYING:**  
 TRAILER WEIGHT: 2,000 LBS.  
 TONGUE WEIGHT: 200 LBS.

**PRO INSTALL TIME: 45 MIN.**  
**NOVICE INSTALL TIME: 90 MIN.**

IF YOU ARE HESITANT TO UNDERTAKE THIS TASK ON YOUR OWN, CONTACT AN AUTHORIZED CURT INSTALLER FOR ADDITIONAL ASSISTANCE.

**INSTALLATION REQUIRES:**


<b>RATCHET</b>	<b>TORQUE WRENCH</b>	<b>3/4" 10mm SOCKETS</b>
<b>9" SOCKET EXTENSION</b>	<b>T-25 TORXBIT SOCKETS</b>	<b>ROTARY TOOL</b>
<b>TAPE MEASURE</b>	<b>MASKING TAPE</b>	<b>CUT-OFF WHEEL</b>
<b>SILICONE CAULK</b>	<b>SAFETY GLASSES</b>	

**INSTALLATION TIPS:**

- BEFORE YOU BEGIN INSTALLATION, READ ALL INSTRUCTIONS THOROUGHLY.
- TO EASE INSTALLATION, 2 PEOPLE MAY BE REQUIRED.
- USING PROPER TOOLS WILL GREATLY IMPROVE THE QUALITY OF THE INSTALL AND REDUCE THE TIME REQUIRED.
- NEED HELP OR HAVE SOME QUESTIONS? CALL TECHNICAL SUPPORT AT 800.798.0813


**LEVEL OF DIFFICULTY: MODERATE**

EASY	MODERATE	CHALLENGING
- NO DRILLING REQUIRED		
- FASCIA TRIMMING REQUIRED		




# INSTALLATION WALKTHROUGH:

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	1_2 - 13 x 5 HEX	HEX BOLT
2	4	1/2"	CONICAL TOOTHED WASHER
3	2	CM-SP62	.250" SPACER PLATE
4	2	1/2-13 x 1 1/2	CARRIAGE BOLT
5	2	HFN 1213	HEX FLANGE NUT
6	2	11423-NPWA	NUT PLATE WELDMENT



1. Remove the (3) fascia screws holding the rear plastic fascia to the bottom of the trunk pan. Retain (2) screws for reinstallation in Step (9) and return (1) screw to owner. **Note:** For 2016 models remove (2) inboard T-30 screws that retain exhaust tips (1) on each side, and remove exhaust tips.



2. Remove the spare tire from inside the trunk.



## INSTALLATION WALKTHROUGH:

3. Remove the (2) rearmost rubber drain plugs from the bottom of the trunk pan and return to owner.


**Note:** To ease installation lower exhaust by removing (2) nuts using 10mm socket from the exhaust bracket (1) on each side.



4. Mark and trim rear fascia.

**Note:** For 2016 models use 10mm socket to remove (4) bolts (2) on each side and remove (2) fascia brackets (1) on each side from vehicle and trim for clearance as shown.

**Note:** Dimensions are approximate, confirm fit prior to trimming.



5. Reattach trimmed fascia brackets. Gently flex the rear fascia and place nut plates on top of the bumper beam supports.




6. Raise hitch into position, aligning the slots in the hitch with the holes in the nut plates. Loosely secure the hitch into position using (4) 1/2-13 x 5" hex bolts and 1/2" conical toothed washers (2) each side.





## INSTALLATION WALKTHROUGH:

7. Seal the drain holes in the trunk pan with silicone caulk. Insert a SP62 spacer and 1/2-13 x 1 1/2" carriage bolt into each of the drain holes and secure from below with 1/2" hex flange nut.



8. Torque all 1/2-13 x 5" hex bolts to 75 ft-lbs. Torque all remaining 1/2" hardware to 110 ft-lbs. Return the spare tire to the trunk.




9. Reinstall the (2) outer screws through the bumper fascia and into the trunk pan.



## TOWING SAFETY INFORMATION


### Gross Trailer Weight / GTW

The Gross Trailer Weight is the weight of the trailer & cargo. Measure this by putting the fully loaded trailer on a vehicle scale.



### Tongue Weight / TW

The downward force that is exerted on the hitch ball by the coupler. The tongue weight will vary depending on where the load is positioned in relationship to the trailer axle(s). To measure the tongue weight, use either a commercial scale or a bathroom scale with the coupler at towing height. When using a bathroom scale with heavier tongue weights, use the method shown and multiply the scale reading by 3.



### Weight Carrying / WC

The total weight of both the trailer and the cargo inside. Never exceed the weight capacity of your trailer hitch.

### Weight Distribution / WD

Used to balance the weight of the cargo between the front and rear wheels throughout the trailer, allowing for better steering, braking, and level riding.



### Sway Control

A device used to reduce the lateral movements of the trailer that are caused by the wind. This works in conjunction with a weight distribution hitch. Do not use this on a class 1 or 2 hitch, or with surge brakes.

### How Much Can You Safely Tow?

TONGUE WEIGHT (lb)	1000	2000	3000	4000	5000	6000	7000	8000	10,000	12,000
Tongue weight should be about 10 to 15 percent of the gross trailer weight.										
CLASS 1										
CLASS 2										
CLASS 3										
CLASS 4										
CLASS 5										
TRAILER TYPE										
Coupler	1 1/2"	1 3/4"	1 3/4"	1 3/4"	1 3/4"	1 3/4"				
1-1/2" Coupler	1100	1200	1300	1400	1500	1600				
2" Coupler	1800	1800	1800	2000	2200	2400	2600	2800	3000	3200
2 1/2" Coupler	2100	2400	2700	3000	3300	3600	3900	4200	4500	4800
3" Coupler	2800	3200	3600	4000	4400	4800	5200	5600	6000	6400
3 1/2" Coupler										
4" Coupler										
4 1/2" Coupler										
5" Coupler										
5 1/2" Coupler										
6" Coupler										
6 1/2" Coupler										
7" Coupler										
7 1/2" Coupler										
8" Coupler										
8 1/2" Coupler										
9" Coupler										
9 1/2" Coupler										
10" Coupler										
10 1/2" Coupler										
11" Coupler										
11 1/2" Coupler										
12" Coupler										
12 1/2" Coupler										
13" Coupler										
13 1/2" Coupler										
14" Coupler										
14 1/2" Coupler										
15" Coupler										
15 1/2" Coupler										
16" Coupler										
16 1/2" Coupler										
17" Coupler										
17 1/2" Coupler										
18" Coupler										
18 1/2" Coupler										
19" Coupler										
19 1/2" Coupler										
20" Coupler										
20 1/2" Coupler										
21" Coupler										
21 1/2" Coupler										
22" Coupler										
22 1/2" Coupler										
23" Coupler										
23 1/2" Coupler										
24" Coupler										
24 1/2" Coupler										
25" Coupler										
25 1/2" Coupler										
26" Coupler										
26 1/2" Coupler										
27" Coupler										
27 1/2" Coupler										
28" Coupler										
28 1/2" Coupler										
29" Coupler										
29 1/2" Coupler										
30" Coupler										
30 1/2" Coupler										
31" Coupler										
31 1/2" Coupler										
32" Coupler										
32 1/2" Coupler										
33" Coupler										
33 1/2" Coupler										
34" Coupler										
34 1/2" Coupler										
35" Coupler										
35 1/2" Coupler										
36" Coupler										
36 1/2" Coupler										
37" Coupler										
37 1/2" Coupler										
38" Coupler										
38 1/2" Coupler										
39" Coupler										
39 1/2" Coupler										
40" Coupler										
40 1/2" Coupler										
41" Coupler										
41 1/2" Coupler										
42" Coupler										
42 1/2" Coupler										
43" Coupler										
43 1/2" Coupler										
44" Coupler										
44 1/2" Coupler										
45" Coupler										
45 1/2" Coupler										
46" Coupler										
46 1/2" Coupler										
47" Coupler										
47 1/2" Coupler										
48" Coupler										
48 1/2" Coupler										
49" Coupler										
49 1/2" Coupler										
50" Coupler										
50 1/2" Coupler										
51" Coupler										
51 1/2" Coupler										
52" Coupler										
52 1/2" Coupler										
53" Coupler										
53 1/2" Coupler										
54" Coupler										
54 1/2" Coupler										
55" Coupler										
55 1/2" Coupler										
56" Coupler										
56 1/2" Coupler										
57" Coupler										
57 1/2" Coupler										
58" Coupler										
58 1/2" Coupler										
59" Coupler										
59 1/2" Coupler										
60" Coupler										
60 1/2" Coupler										
61" Coupler										
61 1/2" Coupler										
62" Coupler										
62 1/2" Coupler										
63" Coupler										
63 1/2" Coupler										
64" Coupler										
64 1/2" Coupler										
65" Coupler										
65 1/2" Coupler										
66" Coupler										
66 1/2" Coupler										
67" Coupler										
67 1/2" Coupler										
68" Coupler										
68 1/2" Coupler										
69" Coupler										
69 1/2" Coupler										
70" Coupler										
70 1/2" Coupler										
71" Coupler										
71 1/2" Coupler										
72" Coupler										
72 1/2" Coupler										
73" Coupler										
73 1/2" Coupler										
74" Coupler										
74 1/2" Coupler										
75" Coupler										
75 1/2" Coupler										
76" Coupler										
76 1/2" Coupler										
77" Coupler										
77 1/2" Coupler										
78" Coupler										
78 1/2" Coupler										
79" Coupler										
79 1/2" Coupler										



# 11423

# AUDI A6

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY 18050 STABILIZING STRAPS.





**WARNING: \*\* FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY \*\***

**WARNING: \*\*\* DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY \*\*\***



Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	1_2 - 13 x 5 HEX	HEX BOLT
2	4	1/2"	CONICAL TOOTHED WASHER
3	2	CM-SP62	.250" SPACER PLATE
4	2	1/2-13 x 1 1/2	CARRIAGE BOLT
5	2	HFN 1213	HEX FLANGE NUT
6	2	11423-NPWA	NUT PLATE WELDMENT



**FRONT**  
↑  
**REAR**

TOOLS REQUIRED
RATCHET
TORQUE WRENCH
3/4" & 10mm SOCKET
9" EXSTENSION
T-25 AND T-30 TORXBIT
ROTARY CUTTING TOOL
MASKING TAPE
TAPE MEASURE
SILICONE CAULK
SAFETY GLASSES

HITCH WEIGHT: 40 LBS.


INSTALL TIME

PROFESSIONAL: 45 MINUTES

NOVICE (DIY): 90 MINUTES

INSTALL NOTES:


- NO DRILLING REQUIRED
- FASCIA TRIMMING REQUIRED



**NOTE: DIMENSIONS ARE APPROXIMATE, CONFIRM FIT PRIOR TO TRIMMING**

FASCIA TRIM DIAGRAM

**PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.**



HITCH SHOWN IN PROPER POSITION

FASCIA BRACKET TRIM DIAGRAM

## INSTALLATION STEPS

1. Remove the (3) fascia screws holding the rear plastic fascia to the bottom of the trunk pan. Retain (2) screws for reinstallation in Step 9 and return (1) screw to owner.  
**Note:** For 2016 models remove (4) inboard T-30 screws that retain exhaust tips (2) on each side.
2. Remove the spare tire from inside the trunk.
3. Remove the (2) rearmost rubber drain plugs from the bottom of the trunk pan and return to owner.  
**Note:** To ease installation lower exhaust by removing (2) nuts using 10mm socket from the exhaust bracket (1) on each side.
4. Mark and trim the rear fascia.  
**Note:** For 2016 models use 10mm socket to remove (4) bolts (2) on each side to remove (2) fascia brackets (1) on each side from vehicle and trim for clearance as shown.  
**Note:** Dimensions are approximate, confirm fit prior to trimming.  
(See Fascia Trim Diagram)
5. Reattach trimmed fascia bracket. Gently flex the rear fascia and place the nut plates on top of the bumper beam supports.
6. Raise the hitch into position, aligning the slots in the hitch with the holes in the nut plates. Loosely secure the hitch into position using (4) 1/2-13 x 5" hex bolts and 1/2" conical toothed washers (2) each side.
7. Seal the drain holes in the trunk pan with silicone caulk. Insert a SP62 spacer and 1/2-13 x 1 1/2" carriage bolt into each of the drain holes and secure from below with 1/2" hex flange nuts.
8. Torque all 1/2-13 x 5" hex bolts to 75 ft-lbs. Torque all remaining 1/2" hardware to 110 ft-lbs.
9. Return the spare tire to the trunk.
10. Reinstall the (2) outer screws through the bumper fascia and into the trunk pan.

**PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.**