

56172 FORD EXPLORER

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Locate the vehicle's OEM trailer wiring harness connector on the passenger side behind the rear tire (A). The connector will be similar to the one on the 4-Flat harness.

2. Separate the connectors taking care not to damage the locking tabs. Insert the new 4-Flat harness' connectors between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.

4. Route the 4-Flat back along the bumper avoiding the exhaust to the rear of the vehicle and secure in a convenient out of the way location near the hitch.





Find more CURT products on our website.

Learn more about trailer hitches and towing we have.