

INSTALLATION INSTRUCTIONS

DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE'S LAMP LOAD RATING, WHICHEVER IS LOWER

56225 APPLICATIONS

Make	Model
Nissan	Frontier
Nissan	Pathfinder
Nissan	Xterra
Suzuki	Equator

VEHICLE-TO-TRAILER CONNECTOR



NOTE

All steps must be followed to ensure the CURT wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

TOOLS NEEDED

Panel trim removal tool
Flat blade screwdriver
Side cutter

WIRING LOCATION GUIDE

SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S5 - Behind driver side rear bumper



PICKUP TRUCKS (T)

Representative vehicle shown below

T3 - Behind driver side rear bumper



WARNING

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION

Step 1

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

Step 2

Connect the CURT relay harness to the vehicle wiring harness, located on the passenger side behind the kick panel.

Remove the sill plate by pulling upwards (A).

Step 3

Remove the passenger side kick panel to access the vehicle 12-pin wiring connector (B). The connector will be similar to that on the harness with the relays.

Step 4

Insert the CURT harness with relays into the vehicle 12-pin connector. Make sure that the connectors are fully inserted with the locking tabs in place. Secure any loose wires with the provided cable ties.

Step 5

The vehicle factory tow plug is located on the driver side, along the frame rail behind the rear bumper (C). The connector will be similar to the one on the 4-flat harness. Remove the protective cap, taking care not to damage the locking tabs.

Step 6

Insert the 4-flat harness connector into the vehicle tow harness connector making sure that the locking tab is in place (D,E).

Step 7

Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location.

Step 8

Use the cable ties provided to secure any loose wires. Be sure to avoid any sharp edges and hot exhaust areas.

Step 9

Reinstall all items removed during install and reconnect negative battery terminal.

