

11707

91-96 INFINITI G20 SEDAN

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY 18050 STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	4	M10-1.25 x 35	HEX BOLT
2	4	7/16"	CONICAL TOOTHED WASHER

RUBBER ISOLATOR REMOVAL DIAGRAM

This technique can be used if and Exhaust Hanger Removal Pliers is not available.


Using a 5/8" open end wrench, slide the wrench up to the rubber isolator, cradling the hanger rod as shown. Next place the flat edge of a pry bar between the wrench and the hanger stop or hanger rod. Then simply rotate the pry bar toward the wrench to remove the rubber isolator.

Note: Using a spray lubricant or soapy water on the hanger rod and the rubber isolator helps removal.



WELDNUT CLEANING

To remove debris from weldnuts in frame, spray lubricant or compressed air into hole. For heavy debris, use a small wire brush. (Be careful not to damage threads).



PASSENGER SIDE FRAME RAIL

EXISTING WELDNUTS
(BOTH SIDES)

DRIVER SIDE FRAME RAIL

DESIGNED FOR USE WITH
BALLMOUNT #55001 / 45501

FRONT
↑
REAR

HITCH WEIGHT: .26 LBS.

INSTALL TIME

PROFESSIONAL: .45 MINUTES

NOVICE (DIY): .90 MINUTES

INSTALL NOTES:

NO DRILLING REQUIRED
FACIA TRIMMING MAYBE REQUIRED
LOWER EXHAUST

INSTALLATION STEPS

- Under the rear of the vehicle, locate the driver and passenger side frame rails. The driver's side frame rail includes a bolted on tie down bracket. Remove the bracket and return to the vehicle's owner for reinstallation should the hitch ever be removed.
- Remove the rear exhaust hanger (passenger side) temporarily for mounting clearance. Place hitch up to the bottom of the frame rails at the weldnuts. Trim bumper fascia material at hitch brackets if necessary.
- Using fasteners as shown, mount the hitch to the frame rails. Be certain to use conical washers so the dished side is toward the hitch.
- Torque all 10mm fasteners to 36 lb-ft.
- Reinstall exhaust.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.