


15303**1997-2003 FORD F-150 & F-250 LD (NEW BODY STYLE)**

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	6	9/16-12 x 1 3/4, GR8	CARRIAGE BOLT
2	6	9_16-12, GR8	HEX FLANGE NUT
3	6	CM-SP73	.250 x 1.25 x 2.00" 9/16" SQUARE HOLE SPACER



HITCH WEIGHT: 59 LBS.

INSTALL TIME

PROFESSIONAL: 20 MINUTES

NOVICE (DIY): 40 MINUTES

INSTALL NOTES:

- NO DRILLING REQUIRED

INSTALLATION STEPS

1. Place 9/16" carriage bolts and SP73 spacers through holes in the frame rails
2. Align hitch with carriage bolts and raise hitch into position.
3. Secure hitch to the frame rail using 9/16" flange nuts.
4. Torque all 9/16" fasteners to 150 ft-lbs.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.