

55265

FORD F-250 & F-350 HEAVY DUTY

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

6/8/09

1. Locate the vehicles trailer wiring harness behind the rear bumper next to the spare tire. **A** The vehicles harness will have a connector that is similar to the connector on the harness.


2. Insert the harness connector into the vehicles connector. **B** Make sure the connectors are fully inserted with locking tabs in place.

3. Route the 4-flat to the center of the vehicle and secure in a convenient out of the way location. Secure any loose wires with the cable ties provided.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.





55265