

55307

TOYOTA RAV4

WIRING LOCATION GUIDE



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open rear hatch. Remove the rear threshold plate, storage covers and floor covering (A,B).

2. Partially remove the rear interior trim panels on both the driver and passenger sides of the vehicle (C). Several trim panel fasteners will need to be removed to remove the panels. Set aside all items removed taking care not to damage parts.

3. On the driver and passenger sides of the vehicle, locate the vehicle's taillight wiring harness. The taillight wiring harness will have connectors similar to the ends of the T-Connector. Separate the connectors, taking care not to damage the locking tabs. All connector surfaces should be clean and free of dirt.

4. On the passenger side, insert the T-Connector end with the green wire between the vehicle wiring connectors and lock into place. Be sure that connectors are fully inserted with locking tabs in place.

5. Route the T-Connector end with the yellow wire to the driver's side behind the panels and along the threshold. Insert the T-Connector end with the yellow wire between the vehicle wiring connectors and lock into place.

6. Adhere the black converter box to the frame of the vehicle using the double-sided tape provided. Secure any loose parts of the T-Connector with the cable ties provided.

7. Reinstall all items removed during installation.





55307