

# 55347

BUICK ROADMASTER  
CHEVROLET CAPRICE  
CHEVROLET IMPALA SS

## WIRING LOCATION GUIDE



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Open the trunk and carefully pull back on the vehicles felt trunk liner on the drivers side of the trunk behind the taillight. **[A]** Behind the felt trunk liner locate the vehicles taillight wiring harness the harness will have connectors similar to those on the T-connector harness.

2. Separate the connectors being sure not damage the locking tabs. Insert the T-connector in-between the separated connectors make sure they are fully inserted with locking tabs in place.

3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

4. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the trunk.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

