

# 55358

TOYOTA CAMRY

## WIRING LOCATION GUIDE



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

1. Locate the vehicle wiring inside the vehicle's trunk by removing each of the plastic trim panels. There will be connection points matching the ends of the T-connector. **A**

2. Beginning with the driver's side, separate the vehicle's wiring connectors, being careful not to break the locking tabs. Attach each end to the T-connector containing the yellow wire. Ensure that the connectors are fully inserted with locking tabs in place. **B**


3. Remove rear trunk fascia inside the trunk and route the wire to the passenger side of the vehicle. Repeat step 2 using the T-connector containing the Green wire.

4. Locate a suitable grounding point near the adapter. Drill a 3/32" hole and secure the white wire using the eyelet and screw provided.

5. Secure the any loose wires and the black converter box to the vehicle using the cable ties and double sided tape provided. Reattach all trim panels.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage to vehicle and/or personal injury.





55358