

# 55360

HONDA PASSPORT  
ISUZU AMIGO  
ISUZU RODEO  
ISUZU RODEO SPORT

## WIRING LOCATION GUIDE



### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



1. Remove the drivers and passenger side taillight assemblies by removing the three phillips head screws holding them in place. **A** The third screw is hidden between the taillight assembly and the bumper. **B** Disconnect each of the taillight assembly connectors from the vehicle harness connectors. **C**

2. Starting on the driver's side route the T-connector end with the yellow wire up behind the bumper, through the opening under the taillight assembly. **D** Insert the T-connector end with the yellow wire in-between the connectors disconnected in step 1.

3. Route the T-connector end with the green wire along the back of the bumper to the passenger side, then up through the opening on the passenger side. Then insert the T-connector end with the green wire in-between the connectors disconnected in step 1.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

6. Re-install the taillight assemblies and secure any loose wires with the cable ties provided.

### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.



55360